




Cable connection



MASTER/SLAVE FUNCTION




Cable connection




switchDIM OPERATING INSTRUCTION

- The integrated switchDIM function allows a direct connection to a push button for dimming and switching. The dimming range is 1%-100%.
- The dimming level is saved at power-down and restored at power-up.
  - Short press (<0.6 s) to turn the light ON or OFF.
  - Long press for 1-6 seconds to adjust brightness. After releasing and pressing again, the light will dim in the opposite direction.
  - Long press for 20 seconds to switch the fade time between 3 seconds and 6 seconds. The factory default setting is 3 seconds.
  - Long press for 10 seconds four times, with intervals no longer than 2 seconds, to restore brightness, fade time, and dimming direction to factory default settings.
  - If multiple switchDIM-enabled lights with different dimming levels or opposite dimming directions are connected to the same push button, a 10-second press will synchronize them to a 50% brightness level with a uniform dimming direction. The fade time cannot be synchronized.



VENTUS  
LIGHT BY SWEDEN®




Cable connection




MASTER/SLAVE FUNCTION




Cable connection



Cable connection



Cable connection



LIGHT BY SWEDEN®